

Meridian IVR

3270 Gateway Development Guide

Publication number: 555-9001-312
Product release: Meridian IVR 2.0/I
Document release: Standard 1.0
Date: February 1996

© 1996 Northern Telecom
All rights reserved

Printed in the United States of America

Information is subject to change without notice. Northern Telecom reserves the right to make changes in design or components as progress in engineering and manufacturing may warrant.

Nortel, Meridian IVR, Meridian Mail, ACCESS, and Meridian 1 are trademarks of Northern Telecom. DEC and VT420 are trademarks of Digital Equipment Corporation. HP, LaserJet, and ThinkJet are trademarks of Hewlett-Packard Company. X Window System and X are trademarks of the Massachusetts Institute of Technology. NCD is a trademark of Network Computing Devices Inc. UNIX is a registered trademark of AT&T. Voicetek and VTK are trademarks of Voicetek Corporation. Motif is a trademark of Open Software Foundation Inc. Touch tone is a trademark of Bell Canada. IBM is a trademark of International Business Machines Incorporated.

Publication history

February 1996

This document is the first standard issue for Meridian IVR release 2.0/I.

Contents

About this guide ix

Who should use this guide.	ix
How to use this guide.	ix
Additional Nortel manuals	x
Conventions used in this guide	xi

Chapter 1: About the 3270 gateway 1-1

The 3270 communication protocol.	1-1
The 3270 gateway hardware and software	1-3
Terminal Resource Server.	1-4
TRSC.	1-5
Vendor communication software and hardware.	1-5
TRS configurations	1-5

Chapter 2: Template files 2-1

Determining the required transactions.	2-1
Action templates	2-4
Action template syntax	2-5
Screen templates.	2-13
Screen template syntax.	2-15
Initial-action templates.	2-26

Chapter 3: Getting started 3-1

Setting up the trs.conf file	3-2
Setting up the trs.sdf file	3-7
A complete sample transaction	3-9
Initial-action template.	3-9
Action template performing a transaction	3-13

Chapter 4: Meridian IVR 2.0/I call flow interface 4-1

Using the COMI, COMO, and COMA cells to access the host computer	4-2
Setting the COMI cell parameters	4-3
Setting the COMO cell parameters	4-7
Setting the COMA cell parameters	4-10
Sample application using the COMI, COMO, and COMA cells . .	4-11

Appendix A: SCO A-1

Communication scripts	A-2
---------------------------------	-----

Appendix B: Host connectivity B-1

IBM 3270 emulation characteristics	B-1
3270/5250 SNA/SDLC card	B-2
3270/5250 Token Ring card	B-2
9-Pin connector pinouts	B-4
Configuring 3270 for SDLC host communications	B-4
Verifying that Express recognizes the hardware	B-9
Defining the node	B-10
Defining the link	B-13
Defining the station	B-17
Defining the logical unit	B-19
Defining the 3270 users/sessions	B-21
Configuring 3270 for Token Ring host communications	B-27
Verifying that Express recognizes the hardware	B-33
Defining the node	B-34
Defining the link	B-37
Defining the station	B-41
Defining the logical units	B-43
Defining the 3270 users/sessions	B-45
Testing 3270 and 5250 host communications	B-53

Glossary**Glossary-1**

List of figures

Figure 1-1	Terminals connected to a mainframe	1-2
Figure 1-2	Logical terminal sessions running on a host computer	1-3
Figure 1-3	3270 gateway configuration	1-4

Figure 2-1	Terminal operator vs. voice response system.....	2-3
Figure 2-2	Action and screen templates.....	2-4
Figure 2-3	Action template syntax	2-6
Figure 2-4	Action template example	2-7
Figure 2-5	Reset-action template sequence sample	2-9
Figure 2-6	Reset-action template sample.....	2-10
Figure 2-7	Logout action flow	2-11
Figure 2-8	Logout-action template sample	2-12
Figure 2-9	Fields and the system prompt.....	2-14
Figure 2-10	Fields in a host computer application.....	2-15
Figure 2-11	Screen template syntax.....	2-16
Figure 2-12	Screen template example	2-17
Figure 2-13	Field-descriptor syntax	2-20
Figure 2-14	Format of key-descriptor line.....	2-23
Figure 2-15	Sleep-descriptor format.....	2-25
Figure 3-1	trs.conf file syntax	3-3
Figure 3-2	Initial-action template	3-4
Figure 3-3	trs.conf file sample	3-6
Figure 3-4	trs.sdf file sample	3-8
Figure 3-5	Initial-action template sample.....	3-10
Figure 3-6	Logout-action used by initial-action template	3-12
Figure 3-7	Action template sample	3-14
Figure 3-8	Reset-action template sample.....	3-15
Figure 3-9	Logout-action template sample	3-16
Figure 4-1	Accessing the mainframe.....	4-1
Figure 4-2	Activating the gateway from a COMI cell	4-2
Figure 4-3	COMI cell parameter window	4-4
Figure 4-4	COMO cell parameter window	4-7
Figure 4-5	COMO cell.....	4-9
Figure 4-6	COMA cell in the clean-up handler	4-11
Figure 4-7	Application accessing the TRS process from the COMI and COMO cell.....	4-12
Figure 4-8	COMI, COMO cell parameters, TRS templates, and host screens.....	4-14
Figure B-1	ARNET SDLC card	B-2
Figure B-2	Madge Smart 16/4 AT Plus Ringnode token ring host cardB-3	
Figure B-3	Token Ring pin arrangements.....	B-3
Figure B-4	Subminiature STP cable pinouts.....	B-4

List of tables

Table 1-1	Vendor software and hardware	1-5
Table 2-1	Valid field I/O entries	2-22
Table 2-2	Valid key names.....	2-24
Table 4-1	Branches of COMO cell	4-10
Table 4-2	Application cell functions for Figure 4-7	4-13
Table A-1	Default settings for Express	A-1

List of procedures

Procedure 2-1	Accessing transaction information	2-5
---------------	---	-----